

Retrofit Kit

GPS-IMEASURE-D™

This kit is designed to make the i-measure-D compatible with building automation systems with a grounded common for input. For the device to work properly it must only have one ground reference. Once installed this kit will provide a ground reference only through output return (pin #4).

CONTENTS

1. Mounting adaptor
2. 4 mounting screws
3. Isolation transformer
4. Revised i-measure-D IOM / instructions

INSTALLATION

1. Disconnect power to i-measure-D
2. Remove i-measure-D from duct /mounting
3. Install bracket onto i-measure-D
4. Reinstall i-measure-D with bracket into ductwork
5. Remove existing input wiring if connected to a shared or grounded transformer/ power supply
6. Install output wires from supplied transformer to pins 1+2 (not polarity sensitive)
7. Connect transformer to appropriate power source.
8. Follow the instructions in the revised i-measure-D IOM provided in this kit



www.globalplasmasolutions.com